

# P900

## 1. Unit doesn't come **ON**

- Make sure unit is plugged in to 120 volt outlet. Push the on button on the display. If touch pad doesn't light up, pad maybe defective.

Replace with part number MSCELC10

## 2. Unit comes **ON** but lamp doesn't light up

- Verify if micro switch is applied lamp's access door .
- Verify lamp continuity with your OHM meter
  - There are 4 pins at one end of the lamp. Using meter probe on one pin, find the corresponding other. Then check the second pair. A GOOD lamp will have continuity on both circuit. A FAULTY lamp has one or both circuit dead.

If lamp is GOOD, replace the ballast: part number BST1200/240GL

If the lamp is FAULTY, replace the lamp : part number LMPRGXJ65 or LMPRGJ65 (no odor control)

## 3. Unit **ON** but making rattling noise or motor not turning

- Motor is defective.

Replace motor : part number MSCMTR8

**Note: part number is etched on the surface of the lamp, close to ceramic end cap.**